


# aPR2060DBC-H2.2 Demo Board

## User Guide

aPR2060DBC-H2.2 is suitable for aPR2060-H2.2 for one message recording.



- STEP-1 : Connect 4.5V - 6V power to the demo board.
  - STEP-2 : Connect speaker to demo board.
  - STEP-3 : Press & hold the “ REC ” key and LED on to start recording.
  - STEP-4 : Say something max. 40 seconds toward “ MIC ”
  - STEP-5 : Release “ REC ” key and LED off to finish recording.
  - STEP-6 : Press & release “ PLAY ” key one time to play your recorded voice.
- 
- If need aPR2060-H2.2 IC details, please visit our website  
<http://www.aplusinc.com.tw> for its data sheet.

## ■ HISTORY

### **Ver. A (2014/05/22)**

- Original version User Guide for aPR2060 H2.2