


aP58DBS-S08 User Manual



1. Part No. : aP58DBS-S08
2. PCB size : 39cm x 33cm
3. PCB No. : 2226
4. VDD : 3V-5V
5. PWM ONLY
6. Function :
 - P00 : SBT KEY : One key sequential trigger
 - P01 : Volume control (V ++)
 - P02 : Volume control (V - -)
 - P03 : LED